

T-PRO 4000 Transformer Protection Relay

Order Template

In order to specify and order an ERLPhase relay properly configured for the application, a part number must be constructed as indicated below:

T-PRO 4000 - aa - bb - ccc - d - e - ff

aa - Model:

- 3U: 3U chassis with 9 digital inputs, 14 digital outputs, 15 CT inputs, 3 PT inputs
2 temperature inputs, horizontal mounting
- 4U: 4U chassis with 20 digital inputs, 21 digital outputs, 12 CT inputs, 6 PT inputs
(Future)

bb - Secondary Input Current:

- 1A: 1 Amp
- 5A: 5 Amp

ccc - External Input Rating:

- 048: 48/125/250 Vdc set to 48 Vdc
- 125: 48/125/250 Vdc set to 125 Vdc
- 250: 48/125/250 Vdc set to 250 Vdc

d - Internal Modem:

- 0: No internal modem card, standard
- 1: Factory installed modem card

e - Communications - option for LAN Ports 1 and 2:

- 0: C – OP: one copper, one optical
- 1: OP – OP: both optical

C = Copper, RJ-45, 100BASE-T

OP = Optical 100BASE-FX, multimode, 1300 nm, ST style connector

ff - Operating Frequency:

- 50: 50 Hertz
- 60: 60 Hertz

Example:

T-PRO 4000 – 3U – 5A – 125 – 0 – 1 – 60: This part number specifies a T-PRO 4000 relay with 5 Amp secondary input current, 125 Vdc rated external inputs, no modem card, with both LAN ports to be used for optical communications, suitable for operation on 60 Hertz system.

Note:

The T-PRO 4000 comes standard in a horizontal mounting chassis. The software CD has the latest firmware version and a soft copy of the user manual. The Relay Inoperative is set as Normally Closed and user configurable outputs are set as Normally Open. Please enquire regarding any specific non standard requirements.